

User guide for U-shaped joining brackets

Before use, please check contents to ensure nothing is missing:

- 4x U-shaped brackets
- 4x locking bolts
- 2x 120mm longer bolt to join ramps



To Assemble:

1. First, remove the original fixings from the hinges on the inner and outer ramps. The hinges will now look like the below:



2. Next you will need the 2x 120mm bolts. Fix the wider middle ramp to the two out ramps using these – you will need to use the longer bolts on the centre hinges as shown below:



Long Bolt



THERAMPPEOPLE

3. For the final step you will need the U-shaped brackets and the locking bolts. These need to be fixed on the ramp on above and below the hinges with two either side:

